


Charging the Equine Cushion

- The Equine Cushion comes with 1 Charger
- Make sure power button is turned off before plugging into power
- To charge the cushion you need to first attach the wall plug lead to the charger box (in white box)
- Then plug the charger pin into the charge point in the battery pocket on the cushion.
- The battery is fully charged when the red light on the charger box turns green.
- Charging times are dependent on how low the battery is at the time
- A new Equine Cushion battery should last upto 5.5 hours when fully charged



Charging the Wand

- The Wand comes with 1 Charger
- To charge the wand, plug the charger pin into the charge point on the wand and into a power point.
- The battery is fully charged when the red light on the charger box turns green.
- Charging times are dependant on how low the battery is at the time
- A New Wand Battery should last upto 6 hours fully charged



**TO GET THE BEST LIFE OUT OF THE BATTERY
DO NOT STORE THEM FLAT OR SEMI CHARGED
FOR EXTENDED PERIODS OF TIME**